品名：CTF-01M取説
サイズ：210×290　20ページ
材質：上質紙 菊判48.5kg（81.4g/㎡）
刷色：1C（Black）
Black

WOOZOO®
by IRIS OHYAMA

สำหรับใช้งานภายในอาคารและครัวเรือน

พัดลมไอเย็น
KSWK-0603D
คู่มือการใช้งาน



สารบัญ

การเตรียมความพร้อมก่อนการใช้งาน

ข้อควรระวังเพื่อความปลอดภัย..... 2
ข้อควรระวังในการใช้งาน..... 4
กลไกของพัดลมไอเย็น..... 4
ชิ้นส่วนต่างๆ..... 5
รีโมทควบคุม..... 7

คำแนะนำในการใช้งาน

การเตรียมการ..... 8
วิธีใช้..... 9
การดูแลรักษา..... 11

อื่นๆ

การแก้ไขปัญหา..... 14
ข้อมูลทางเทคนิค..... 15
การรับประกันและบริการหลังการขาย..... 15
ใบรับประกันสินค้า..... ปกหลัง

确认用

ข้อควรระวังเพื่อความปลอดภัย

กรุณาอ่าน “ข้อควรระวังเพื่อความปลอดภัย” โดยละเอียดเพื่อการใช้งานที่ถูกต้อง
ข้อควรระวังนี้เป็นการอธิบายข้อควรปฏิบัติ เพื่อป้องกันไม่ให้เกิดอันตรายต่อบุคคลและความเสียหายต่อทรัพย์สิน

ความหมายของสัญลักษณ์

สัญลักษณ์นี้หมายถึง “คำเตือน”	สัญลักษณ์นี้หมายถึง “ห้ามทำ”	สัญลักษณ์นี้หมายถึง “คำแนะนำ” ที่จำเป็นต้องปฏิบัติตาม

คำเตือน

สัญลักษณ์นี้หมายถึง การใช้งานที่ผิดวิธีอาจนำไปสู่การเสียชีวิตและการบาดเจ็บร้ายแรง

ใช้งานปลั๊กไฟและสายไฟอย่างถูกวิธี

ตรวจสอบให้แน่ใจว่า

- **ใช้ผ้าแห้งเช็ดทำความสะอาดฝุ่นละอองบนปลั๊กไฟอย่างสม่ำเสมอ**
  การสะสมของฝุ่นอาจเป็นเหตุให้เกิดเพลิงไหม้หรือไฟฟ้าช็อต เนื่องจากฉนวนไฟฟ้าบกพร่อง
- **เสียบปลั๊กไฟเข้ากับเต้ารับให้สุด**
  หากไม่ปฏิบัติตามอาจก่อให้เกิดเพลิงไหม้หรือไฟฟ้าช็อต เนื่องจากไฟฟ้าลัดวงจร

ถอดปลั๊กผลิตภัณฑ์

- **กรุณาถอดปลั๊กไฟออกจากเต้ารับทุกครั้งก่อนทำการดูแลรักษา ตรวจสอบ หรือเคลื่อนย้าย**
  หากไม่ปฏิบัติตามอาจก่อให้เกิดไฟฟ้าช็อตหรือบาดเจ็บ

ห้ามสัมผัสขณะมือเปียก

- **ห้ามเสียบหรือถอดปลั๊กไฟในขณะที่มือเปียก**
  หากไม่ปฏิบัติตามอาจก่อให้เกิดไฟฟ้าช็อต แผลไหม้ หรือการบาดเจ็บ

ห้ามทำ

- **ห้ามใช้งานในขณะที่สายไฟหรือปลั๊กไฟชำรุดเสียหายหรือเต้ารับหลวม**
  หากไม่ปฏิบัติตามอาจก่อให้เกิดเพลิงไหม้หรือไฟฟ้าช็อต เนื่องจากไฟฟ้าลัดวงจร หากสายไฟชำรุดกรุณาติดต่อศูนย์ซ่อมแซมเฉพาะทาง

ห้ามทำ

- **ห้ามเปิดเครื่องหากสายไฟพันกัน**
  หากเปิดเครื่องอาจก่อให้เกิดเพลิงไหม้หรือได้รับบาดเจ็บเนื่องจากความร้อนสูงเกินไป ต้องแน่ใจว่าสายไฟไม่พันกันเมื่อใช้งาน
- **ห้ามทำให้สายไฟชำรุดเสียหาย**
- **ห้ามดึงสายไฟในขณะที่เคลื่อนย้ายหรือจัดเก็บ**
  ห้ามทำให้สายไฟชำรุดเสียหาย ดัดแปลง หัก ดึง บิดงอ วางของหนักทับบนสายไฟ หรือปล่อยให้สายไฟถูกหนีบระหว่างสิ่งของ
  หากสายไฟชำรุดอาจก่อให้เกิดเพลิงไหม้หรือไฟฟ้าช็อต
- **ห้ามใช้งานเต้ารับหรือปลั๊กพ่วงเกินพิกัดแรงดันไฟฟ้าที่กำหนด**
  หากไม่ปฏิบัติตาม
  อาจก่อให้เกิดเพลิงไหม้



- **ห้ามใช้แหล่งจ่ายไฟที่ไม่ใช่กระแสสลับขนาด 220-240V~**
  หากไม่ปฏิบัติตามอาจก่อให้เกิดเพลิงไหม้หรือไฟฟ้าช็อต
- **ห้ามให้เด็กเล็กสัมผัสปลั๊กไฟ**
  หากไม่ปฏิบัติตามอาจก่อให้เกิดการบาดเจ็บหรือไฟฟ้าช็อต

ถอดปลั๊กผลิตภัณฑ์

- **หยุดใช้งานทันทีหากเครื่องทำงานผิดปกติหรือชำรุดเสียหาย และถอดปลั๊กไฟออกจากเต้ารับ**
  หากไม่ปฏิบัติตามอาจก่อให้เกิดควัน เพลิงไหม้ หรือไฟฟ้าช็อต
  (ตัวอย่างความผิดปกติ)
  - **มีเสียงผิดปกติหรือกลิ่นเหม็นไหม้**
  - **ปลั๊กไฟและสายไฟร้อนขึ้นอย่างผิดปกติ**
  - **เมื่อขยับสายไฟแล้วตัวเครื่องติดๆ ดับๆ**
  - **ตัวเครื่องติดๆ ดับๆ ระหว่างใช้งาน**
  - **รู้สึกว่ามีไฟช็อตเบาๆ เมื่อสัมผัสผลิตภัณฑ์**

  ➡กรุณาหยุดใช้งานและติดต่อร้านค้าที่จำหน่ายผลิตภัณฑ์หรือศูนย์บริการของไอริส

ห้ามทำ

- **ห้ามนำไปใช้งานภายนอกอาคาร**
  หากไม่ปฏิบัติตามอาจทำให้ผลิตภัณฑ์ชำรุดเสียหายและก่อให้เกิดไฟฟ้าลัดวงจรหรือเพลิงไหม้

ห้ามทำ

- **ห้ามใช้งานใกล้กับสิ่งที่เป็นเชื้อเพลิง (เช่น น้ำมันก๊าด น้ำมันเบนซิน ทินเนอร์) วัตถุที่ติดไฟได้ (เช่น บุหรี่ ธูป) หรือวัตถุไวไฟ**
- **ห้ามฉีดพ่นของเหลวลงบนผลิตภัณฑ์ (เช่น ยาฆ่าแมลง ผลิตภัณฑ์จัดแต่งทรงผม น้ำมันหล่อลื่น เป็นต้น)**
  หากไม่ปฏิบัติตามอาจก่อให้เกิดเพลิงไหม้

ห้ามถอดแยกชิ้นส่วน

- **ห้ามถอดแยกชิ้นส่วน ซ่อมแซม หรือดัดแปลงผลิตภัณฑ์ด้วยตนเอง**
  ห้ามถอดแยกชิ้นส่วนอื่นนอกจากชิ้นส่วนที่ต้องถอดแยกเมื่อจัดเก็บผลิตภัณฑ์ หากไม่ปฏิบัติตามอาจก่อให้เกิดเพลิงไหม้ ไฟฟ้าช็อต หรือการบาดเจ็บ และอาจเป็นอันตรายหากดำเนินการซ่อมแซมโดยบุคคลอื่นนอกจากช่างผู้เชี่ยวชาญด้านการซ่อมแซม
  ในการซ่อมแซม โปรดติดต่อร้านที่จำหน่ายผลิตภัณฑ์หรือศูนย์ซ่อมแซมเฉพาะทาง

确认用

ห้ามทำ

- **ห้ามใช้งานโดยหันทิศทางลมไปทางอุปกรณ์ที่มีการเผาไหม้ เช่น เตาทำอาหาร**
  หากไม่ปฏิบัติตามอาจก่อให้เกิดการเผาไหม้ที่ไม่สมบูรณ์ หรือมีเปลวเพลิงปลิวตามลม ซึ่งเป็นสาเหตุของการเกิดก๊าซคาร์บอนมอนอกไซด์หรือเกิดเพลิงไหม้



หลีกเลี่ยงการทำให้ผลิตภัณฑ์เปียก

- **ห้ามใช้งานผลิตภัณฑ์ในบริเวณที่เปียกน้ำหรือมีความชื้น เช่น ห้องน้ำ เป็นต้น**
- **ห้ามทำให้ผลิตภัณฑ์เปียกน้ำหรือนำไปแช่น้ำ**
  หากไม่ปฏิบัติตามอาจก่อให้เกิดเพลิงไหม้หรือไฟฟ้าช็อต

ระวัง การใช้งานที่ผิดวิธีอาจนำไปสู่การบาดเจ็บหรือเครื่องชำรุดเสียหาย

ห้ามทำ

- **ห้ามให้ลมกระทบกับร่างกายโดยตรงเป็นเวลานาน**
  โปรดระมัดระวังไม่ให้แรงลมกระทบกับเด็กเล็กหรือผู้สูงอายุโดยตรง เพราะอาจทำให้ร่างกายอ่อนแอลงหรือส่งผลกระทบต่อสุขภาพ
- **ห้ามให้ลมกระทบกับพืชหรือสัตว์โดยตรง**
  หากไม่ปฏิบัติตามอาจก่อให้เกิดผลในแง่ลบต่อพืชและสัตว์

เกี่ยวกับน้ำในถังใส่น้ำ

ตรวจสอบให้แน่ใจว่า

- **เปลี่ยนน้ำในถังใหม่ทุกวัน**
  กรุณาล้างและทำความสะอาดถังใส่น้ำเป็นประจำทุกวัน หากใช้น้ำเก่าอาจก่อให้เกิดกลิ่นเหม็นอับหรือส่งผลเสียต่อสุขภาพ
- **หากไม่ใช้งานผลิตภัณฑ์นานเกิน 1 สัปดาห์ ให้เทน้ำในถังทิ้งและปล่อยให้แผ่นกระจายน้ำแห้งเองโดยธรรมชาติ**
  หากวางทิ้งไว้โดยที่ยังเปียกอยู่ อาจก่อให้เกิดกลิ่นเหม็นอับหรือทำให้อากาศโดยรอบสกปรกได้
- **เทน้ำออกให้หมดเมื่อน้ำในถังมีทีท่าว่าจะแข็งตัว**
  หากน้ำในถังกลายเป็นน้ำแข็ง อาจทำให้บริเวณโดยรอบได้รับความเสียหายเนื่องจากผลิตภัณฑ์ชำรุดหรือมีน้ำรั่วไหล

ห้ามทำ

- **ห้ามใช้น้ำอื่นๆ นอกเหนือจากน้ำสะอาด**
  ห้ามใช้น้ำที่มีอุณหภูมิ 40°C ขึ้นไป สารเคมี สารที่มีกลิ่นหอม (เช่น น้ำมันอโรม่า) น้ำแร่ น้ำด่าง หรือน้ำสกปรก หากใช้งานอาจก่อให้เกิดกลิ่นเหม็นอับหรือทำให้อากาศโดยรอบสกปรกได้
  นอกจากนี้อาจทำให้ผลิตภัณฑ์ผิดรูป เกิดรอยร้าว เปลี่ยนสี หรือมีน้ำรั่วไหลได้

ถอดปลั๊กผลิตภัณฑ์

- **กรุณาจับบริเวณปลั๊กไฟทุกครั้งและห้ามดึงสายไฟขณะถอดปลั๊กไฟ**
  หากไม่ปฏิบัติตามอาจทำให้สายไฟชำรุดเสียหาย เกิดเพลิงไหม้ หรือไฟฟ้าช็อต
- **กรุณาถอดปลั๊กไฟออกจากเต้ารับทุกครั้งเมื่อไม่ได้ใช้งานเป็นเวลานาน**
  หากไม่ปฏิบัติตามอาจก่อให้เกิดเพลิงไหม้หรือไฟฟ้าช็อต

ตรวจสอบให้แน่ใจว่า

- **ใช้งานบนพื้นที่แนวระนาบที่มีความมั่นคง**
  หากใช้งานบนพรมที่มีขนยาว บนที่นอน หรือบนแท่นวางของ อาจทำให้ผลิตภัณฑ์ล้มคว่ำ มีน้ำรั่วไหล หรือได้รับบาดเจ็บ

ห้ามทำ

- **ห้ามปล่อยให้ผู้ที่ไม่คุ้นชินกับการใช้งาน เช่น เด็กเล็ก ใช้งานผลิตภัณฑ์โดยลำพัง และห้ามให้เด็กเล็กสัมผัสผลิตภัณฑ์**
- **ห้ามนั่งหรือพิงไปที่ผลิตภัณฑ์**
  หากไม่ปฏิบัติตามอาจทำให้ผลิตภัณฑ์ล้มคว่ำ มีน้ำรั่วไหล หรือได้รับบาดเจ็บ
- **ห้ามเคลื่อนย้ายตัวเครื่องขณะที่มีน้ำเหลืออยู่ในถัง**
  หากเคลื่อนย้ายขณะที่มีน้ำเหลืออยู่ในถัง เมื่อเครื่องเกิดการเอียงตัวจะทำให้มีน้ำรั่วไหลออกมาได้
  เมื่อต้องการเคลื่อนย้าย ให้เทน้ำในถังทิ้งให้หมด

ห้ามทำ

- **ห้ามใช้งานในบริเวณที่มีสิ่งปิดกั้นกระแสลมอยู่โดยรอบ**
- **ห้ามคลุมหรือปิดด้วยผ้า กระดาษ หรือถุงพลาสติกในขณะที่เครื่องกำลังทำงาน**
- **วางผลิตภัณฑ์ให้ห่างจากผนังด้านหลัง 5 ซม. ขึ้นไป**
- **ใช้งานโดยวางให้ด้านหน้าของผลิตภัณฑ์ห่างจากวัตถุ 30 ซม. ขึ้นไป**
  หากมีการปิดกั้นกระแสลม อาจก่อให้เกิดความร้อนสูงและเกิดเพลิงไหม้ได้



ห้ามทำ

- **ห้ามนำไปใช้งานภายนอกครัวเรือน เช่น การใช้งานเชิงพาณิชย์**
  ผลิตภัณฑ์นี้ผลิตขึ้นเพื่อการใช้งานภายในครัวเรือน หากนำไปใช้งานภายนอกครัวเรือน เช่น การใช้งานเชิงพาณิชย์ อาจก่อให้เกิดเพลิงไหม้ได้

确认用

ข้อควรระวังเพื่อความปลอดภัย (ต่อ)

ห้ามทำ

● **ห้ามใช้งานขณะที่มีการฉีดพ่นยาฆ่าแมลงชนิดควันที่ก่อให้เกิดควันหรือหมอก**
หากไม่ปฏิบัติตามอาจทำให้ส่วนผสมของสารเคมีไปสะสมอยู่ที่แผ่นกระจายน้ำ เมื่อใช้งานครั้งถัดไปจะทำให้สารถูกปล่อยออกมาและก่อให้เกิดผลเสียต่อสุขภาพได้ หลังจากฉีดพ่นยาฆ่าแมลง ให้ระบายอากาศในห้องออกจนหมดก่อนเริ่มใช้งานใหม่อีกครั้ง

ห้ามทำ

● **ห้ามสอดนิ้วหรือสิ่งแปลกปลอม เช่น โลหะ เข้าไปในช่องปล่อยลม ช่องดูดอากาศ หรือซอกอื่นๆ**
หากไม่ปฏิบัติตามอาจก่อให้เกิดไฟฟ้าช็อตหรือการบาดเจ็บ

ข้อควรระวังในการใช้งาน

● **หลีกเลี่ยงการใช้งานในบริเวณที่มีความชื้นหรือควันจากน้ำมันในปริมาณมาก เช่น ห้องครัว**
หากใช้งานในบริเวณนั้นเป็นเวลานาน อาจทำให้ฝุ่นเข้าไปเกาะอยู่ในผลิตภัณฑ์และไม่สามารถขจัดออกด้วยเครื่องดูดฝุ่นได้

● **วางไว้ในจุดที่ไม่กระทบกับแสงแดดหรือโดนลมจากเครื่องปรับอากาศและอุปกรณ์ทำความร้อนโดยตรง**
หากไม่ปฏิบัติตามอาจทำให้ผลิตภัณฑ์เกิดการผิดรูป เปลี่ยนสี หรือทำงานผิดปกติได้

● **ห้ามใช้งานใกล้กับวิทยุหรือโทรทัศน์**
หากไม่ปฏิบัติตามอาจก่อให้เกิดคลื่นรบกวนการทำงานของวิทยุและโทรทัศน์ได้

การทิ้งผลิตภัณฑ์

● **ผลิตภัณฑ์นี้ไม่เหมาะสำหรับบุคคล (รวมถึงเด็กเล็ก) ที่มีความบกพร่องทางร่างกาย ประสาทสัมผัสหรือจิตใจหรือขาดความรู้ความชำนาญ ยกเว้นอยู่ภายใต้การดูแลหรือได้รับคำแนะนำเกี่ยวกับการใช้งานผลิตภัณฑ์อย่างปลอดภัย เด็กต้องอยู่ภายใต้การดูแลเพื่อให้แน่ใจว่าจะไม่เล่นกับผลิตภัณฑ์**

กลไกของพัดลมไอเย็น



* พัดลมไอเย็นจะทำให้น้ำระเหยเป็นไอและทำให้อากาศเย็นขึ้น หากใช้งานในห้องที่ปิดมิดชิดจะทำให้ความชื้นสูงขึ้น และหากใช้งานในบริเวณที่มีความชื้นสูงจะทำให้น้ำระเหยได้ยากขึ้นและทำให้ลมเย็นได้ยากขึ้นอีกด้วย
กรุณาใช้งานในบริเวณที่อากาศถ่ายเทได้ดี หรือใช้งานร่วมกับเครื่องปรับอากาศ

* เมื่อต้องการใช้งานโหมด Cold Wind กรุณาเติมน้ำลงในถังใส่น้ำทุกครั้ง หากไม่มีน้ำในถังจะไม่สามารถทำให้ลมเย็นขึ้นได้

确认用

ชิ้นส่วนต่างๆ

ด้านหน้า

ด้านหลัง (ด้านใน)



确认用

ชิ้นส่วนต่างๆ (ต่อ)

แผงควบคุม

ไฟ Low Water

ขณะใช้งานโหมด Cold Wind หากน้ำในถังใส่น้ำใกล้จะหมด ไฟจะกะพริบและเข้าสู่โหมดการทำงานโดยไม่ใช้ลมเย็น (→P10)



ไฟ/ปุ่ม Cold Wind
สลับโหมดใช้/ไม่ใช้ลมเย็น (→P9)

ไฟ/ปุ่ม Mode
สลับโหมดการทำงาน (→P10)

ไฟ/ปุ่ม Speed
ปรับปริมาณลม (→P9)

ไฟ/ปุ่ม Swing
สลับโหมดใช้/ไม่ใช้การส่าย ปรับทิศทางลมซ้าย-ขวา (→P10)

ไฟ/ปุ่ม Timer Preset
หากกดปุ่มนี้ขณะที่เครื่องทำงานอยู่จะสามารถตั้งเวลาปิดเครื่องได้ และหากกดปุ่มนี้ขณะที่เครื่องปิดอยู่จะสามารถตั้งเวลาเปิดเครื่องได้ (→P11)

ไฟ/ปุ่มเปิด-ปิดเครื่อง
เมื่อกดปุ่มนี้ตัวเครื่องจะเริ่มทำงาน และหากกดซ้ำอีกครั้งตัวเครื่องจะหยุดทำงาน (→P9)

อุปกรณ์เสริม



แพ็คทำความเย็น X2



แบตเตอรี่ขนาด AAA X2 (ใช้ทดสอบการทำงาน)

รีโมทควบคุม

确认用

รีโมทควบคุม

* กรุณาใช้งานโดยหันจุดปล่อยรังสีอินฟราเรดบนรีโมทควบคุมให้ตรงกับส่วนรับสัญญาณรีโมทบนด้านหน้าตัวเครื่อง



จุดปล่อยรังสีอินฟราเรด

ปุ่ม Swing
การทำงานเหมือนกับปุ่ม **Swing** บนตัวเครื่อง (→P10)

ปุ่ม + / - Speed
หากกดปุ่ม + ปริมาณลมจะเพิ่มขึ้น และหากกดปุ่ม – ปริมาณลมจะลดลง (→P9)

ปุ่ม Mode
กลไกการทำงานเหมือนกับปุ่ม **Mode** บนตัวเครื่อง (→P10)

ปุ่มเปิด-ปิดเครื่อง
การทำงานเหมือนกับปุ่มเปิด-ปิดเครื่องบนตัวเครื่อง (→P9)

ปุ่ม Timer Preset
การทำงานเหมือนกับปุ่ม Timer Preset บนตัวเครื่อง (→P11)

ปุ่ม Cold Wind
การทำงานเหมือนกับปุ่ม Cold Wind บนตัวเครื่อง (→P9)

วิธีใส่แบตเตอรี่

- อันดับแรกให้ใส่แบตเตอรี่ขนาด AAA ลงไป 2 ก้อน

*แบตเตอรี่ซึ่งเป็นอุปกรณ์เสริมมีไว้ใช้สำหรับทดสอบการทำงาน กรุณาเปลี่ยนเป็นแบตเตอรี่ก้อนใหม่โดยเร็วที่สุด

- หากขอบเขตการควบคุมของรีโมทแคบลง หรือกดปุ่มแล้วเครื่องไม่ทำงาน กรุณาเปลี่ยนแบตเตอรี่ก้อนใหม่ (แบตเตอรี่ขนาด AAA 2 ก้อน)

เปิดฝาช่องใส่แบตเตอรี่เพื่อเปลี่ยนแบตเตอรี่

① กดฝาช่องใส่แบตเตอรี่ค้างไว้แล้วเลื่อนลงเพื่อเปิด
② ในการเปลี่ยนแบตเตอรี่ ให้นำแบตเตอรี่เดิมออกมาแล้วใส่แบตเตอรี่ก้อนใหม่ลงไปโดยหันขั้ว ⊕ และ ⊖ ให้ถูกด้าน
③ ปิดฝาช่องใส่แบตเตอรี่ให้แน่น



● **หากใส่แบตเตอรี่ผิดวิธี อาจก่อให้เกิดการระเบิด สารเคมีในแบตเตอรี่รั่วไหล เกิดแผลไหม้ หรือก่อให้เกิดความเสียหายปนเปื้อนต่อบริเวณโดยรอบ กรุณาอ่าน "ข้อควรระวังเกี่ยวกับแบตเตอรี่" โดยละเอียดก่อนการใช้งาน**

ข้อควรระวังเกี่ยวกับแบตเตอรี่

ตรวจสอบให้แน่ใจว่า

● **เมื่อใส่แบตเตอรี่ลงไป โปรดตรวจสอบด้านขั้วของแบตเตอรี่ (ขั้วบวก ⊕ และขั้วลบ ⊖) และใส่ให้ถูกต้องตามคู่มือการใช้งาน**
หากใส่แบตเตอรี่ไม่ถูกต้อง อาจก่อให้เกิดการระเบิด สารเคมีในแบตเตอรี่รั่วไหล เกิดเพลิงไหม้หรือได้รับบาดเจ็บ และทำให้บริเวณโดยรอบได้รับความเสียหายปนเปื้อนได้

● **ถอดแบตเตอรี่ออกเมื่อไม่ได้ใช้งานเป็นเวลานาน**
หากไม่ปฏิบัติตามอาจทำให้สารเคมีในแบตเตอรี่รั่วไหล และก่อให้เกิดเพลิงไหม้หรือได้รับบาดเจ็บ หรือทำให้บริเวณโดยรอบได้รับความเสียหายปนเปื้อนได้ หากสารเคมีในแบตเตอรี่รั่วไหล ให้เช็ดสารที่ติดอยู่ในช่องใส่แบตเตอรี่ออกให้หมดและเปลี่ยนแบตเตอรี่ก้อนใหม่ หากสารเคมีที่รั่วไหลออกมาเปรอะเปื้อนร่างกาย ให้ล้างออกจนหมดด้วยน้ำสะอาด

ห้ามถอดแยกชิ้นส่วน

● **ห้ามถอดแยกชิ้นส่วนผลิตภัณฑ์**
หากไม่ปฏิบัติตามอาจก่อให้เกิดความเสียหายต่อผิวกายและเสื้อผ้า

ห้ามทำ

● **ห้ามพกพาหรือจัดเก็บร่วมกับวัตถุขนาดเล็กที่ทำจากโลหะ**
หากไม่ปฏิบัติตามอาจทำให้สารเคมีภายในแบตเตอรี่รั่วไหล หรือเกิดการระเบิดได้เนื่องจากไฟฟ้าลัดวงจร

● **ห้ามใช้งานแบตเตอรี่นอกเหนือจากที่กำหนดไว้**
หากไม่ปฏิบัติตามอาจก่อให้เกิดเพลิงไหม้ ได้รับบาดเจ็บ หรือทำให้เกิดความเสียหายปนเปื้อนต่อบริเวณโดยรอบ เนื่องจากการระเบิดหรือสารเคมีภายในแบตเตอรี่รั่วไหล

● **ห้ามชาร์จแบตเตอรี่**
หากไม่ปฏิบัติตามอาจก่อให้เกิดเพลิงไหม้ ได้รับบาดเจ็บ หรือเกิดแผลไหม้ เนื่องจากการระเบิดและสารเคมีในแบตเตอรี่รั่วไหล

确认用

การเตรียมการ

เติมน้ำใส่ถัง

• กรุณาเติมน้ำใส่ถังเพื่อใช้งานโหมด Cold Wind
*หากไม่ต้องการใช้โหมด Cold Wind แม้ไม่เติมน้ำลงไปก็สามารถใช้งานได้

1 ถอดถังใส่น้ำ

• กดปุ่มถอดถังใส่น้ำค้างไว้และจับบริเวณที่จับถังใส่น้ำแล้วดึงออกมา
• หลังจากที่เครื่องหยุดทำงาน น้ำที่หลงเหลืออยู่ในแผ่นกระจายน้ำจะไหลลงมาทันที ห้ามถอดถังใส่น้ำออกขณะที่ไฟ**เปิด-ปิดเครื่อง**ยังกะพริบอยู่ (ประมาณ 5 นาที)



2 เติมน้ำใส่ถัง

• กรุณาเติมน้ำลงในช่องกักน้ำของถังใส่น้ำ (ฝั่งขวา)
• สำหรับปริมาณน้ำ กรุณาเติมให้สูงกว่า ○ (จ่ายน้ำ) และต่ำกว่า ● (น้ำเต็ม) ของช่องแสดงระดับน้ำ



3 ประกอบถังใส่น้ำ

• สอดถังใส่น้ำเข้าไปจนสุด
• หากช่องดูดน้ำลดระดับลงมา ให้ดันขึ้นไปก่อนแล้วค่อยสอดถังใส่น้ำเข้าไป (→P12)



● **กรุณาใช้น้ำประปาทุกครั้ง และห้ามใช้น้ำที่มีอุณหภูมิ 40°C ขึ้นไป น้ำสกปรก น้ำแร่ น้ำด่าง หรือน้ำจากบ่อน้ำ**
● **ห้ามเติมสารเคมี น้ำหอม หรือน้ำมันหอมระเหยลงไปในน้ำ**
หากไม่ปฏิบัติตามอาจทำให้เชื้อราและเชื้อโรคเพาะพันธุ์ได้ง่ายขึ้นและทำให้แผ่นกรองสกปรก ซึ่งอาจส่งผลกระทบต่อกลิ่นและสุขภาพได้

วิธีใช้แพ็คทำความเย็น

• ทำให้เย็นโดยนำไปแช่ในตู้เย็น จากนั้นนำไปแช่ในช่องกักน้ำเพื่อให้สามารถลดอุณหภูมิของลมเย็นให้ต่ำลงกว่าเดิมได้



• หากต้องการนำแพ็คทำความเย็นไปแช่เย็นอีกครั้ง ให้เช็ดคราบน้ำบนแพ็คออกให้หมดแล้วนำไปแช่ในตู้เย็น

● **กรุณาทำความสะอาดแพ็คทำความเย็นก่อนนำไปใช้ทุกครั้ง**
โดยเฉพาะการนำไปแช่ใกล้กับอาหาร กรุณาล้างให้สะอาดก่อนนำไปใช้งาน

เสียบปลั๊กไฟเข้ากับเต้ารับ



确认用

วิธีใช้

เริ่มต้นใช้งาน

กดปุ่มเปิด-ปิดเครื่องในขณะที่เครื่องหยุดทำงาน

- หากเสียบปลั๊กค้างไว้ ตัวเครื่องจะเริ่มทำงานตามค่าที่ตั้งไว้ในการใช้งานครั้งล่าสุด
- สามารถเปิดเครื่องโดยการกดปุ่มเปิด-ปิดเครื่องบนรีโมทควบคุมได้เช่นกัน

*เวลาเปิดเครื่องที่ตั้งไว้จะถูกยกเลิก

หยุดใช้งาน

กดปุ่มเปิด-ปิดเครื่องในขณะที่เครื่องกำลังทำงาน

- สามารถปิดเครื่องโดยการกดปุ่ม**เปิด-ปิดเครื่อง**บนรีโมทควบคุมได้เช่นกัน
- ตัวเครื่องจะหยุดทำงานและไฟ**เปิด-ปิดเครื่อง**จะกะพริบค้างไว้ประมาณ 5 นาที จากนั้นเครื่องจะดับลง
- หลังจากที่เครื่องหยุดทำงาน น้ำที่หลงเหลืออยู่ในแผ่นกระจายน้ำจะไหลลงมาทันที ห้ามถอดถังใส่น้ำออกขณะที่ไฟ**เปิด-ปิดเครื่อง**ยังกะพริบอยู่

*เวลาปิดเครื่องที่ตั้งไว้จะถูกยกเลิก



ระบบป้องกันการลืมปิดเครื่อง

- หากเปิดเครื่องทิ้งไว้โดยไม่มีการตั้งค่านานเกินกว่า 15 ชั่วโมง ตัวเครื่องจะหยุดทำงานและดับลงโดยอัตโนมัติ

โหมดลมเย็น

- หากกดปุ่ม **Cold Wind** ขณะที่เครื่องกำลังทำงานอยู่ ตัวเครื่องจะเข้าสู่โหมด Cold Wind
- หากกดปุ่มนี้ซ้ำอีกครั้ง ตัวเครื่องจะหยุดปล่อยลมเย็นและสลับเข้าสู่โหมดปล่อยลมเพียงอย่างเดียว



*ในการใช้งานโหมด Cold Wind กรุณาเติมน้ำลงในถังให้ระดับน้ำสูงกว่า ○ (จ่ายน้ำ) และต่ำกว่า ● (น้ำเต็ม) (→P8)

การปรับปริมาณลม

- ทุกครั้งที่กดปุ่ม **Speed** ในขณะที่เครื่องกำลังทำงาน ปริมาณลมจะเปลี่ยนตามลำดับต่อไปนี้

→ 1 → 2 → 3 → 4 ←

- ในการใช้งานผ่านรีโมทควบคุม หากกดปุ่ม + บนปุ่ม **Speed** ปริมาณลมจะมากขึ้น และหากกดปุ่ม – ปริมาณลมก็จะน้อยลง



1 ↔ 2 ↔ 3 ↔ 4

确认用

วิธีใช้ (ต่อ)

การเปลี่ยนโหมด

- ทุกครั้งที่กดปุ่ม **Mode** ในขณะที่เครื่องกำลังทำงาน โหมดจะเปลี่ยนไปตามลำดับต่อไปนี้



→ General → Natural → Sleep

General	ตัวเครื่องจะทำงานด้วยปริมาณลมที่ตั้งไว้ในปุ่ม **Speed**
Natural	ตัวเครื่องจะปรับเปลี่ยนปริมาณลมให้ใกล้เคียงกับธรรมชาติ (ลมธรรมชาติ)
Sleep	ตัวเครื่องจะปล่อยลมแบบธรรมชาติ และค่อยๆ ลดปริมาณลมลง

โหมด Swing

- หากกดปุ่ม **L&R Swing** ขณะที่เครื่องกำลังทำงาน ทิศทางของลมจะเป็นการส่ายซ้าย-ขวา
- หากกดปุ่มนี้อีกครั้งจะเป็นการหยุดส่าย



การปรับทิศทางลมขึ้น-ลง

- สามารถใช้มือปรับใบปรับทิศทางลมขึ้น-ลงได้



หากไฟ Low Water กะพริบ

- หากน้ำในถังใกล้จะหมดขณะที่พัดลมทำงานอยู่ในโหมด Cold Wind ตัวเครื่องจะสลับเข้าสู่โหมดไม่ใช้ลมเย็น
- หากไฟโหมด Cold Wind ดับลง ไฟ Low Water จะกะพริบ

- เติมน้ำลงในถังและประกอบเข้าไปใหม่อีกครั้ง (→P8) จากนั้นกดปุ่ม Cold Wind สองครั้ง ไฟ Low Water จะดับลงแล้วเริ่มเข้าสู่โหมด Cold Wind อีกครั้ง



*นอกเหนือจากการจ่ายน้ำแล้ว หากถอดหรือใส่ถังใส่น้ำ ไฟ Low Water ก็จะกะพริบเช่นกัน ในโหมด Cold Wind หลังจากประกอบถังใส่น้ำให้แน่นแล้วกรุณากดปุ่ม Cold Wind ซ้ำ 2 ครั้ง

确认用

การตั้งเวลาเปิด-ปิดเครื่อง

การตั้งเวลาปิด

- ทุกครั้งที่กดปุ่ม **Timer Preset** ในขณะที่เครื่องกำลังทำงาน ไฟจะสว่างขึ้นตามลำดับต่อไปนี้และเริ่มตั้งเวลาปิดเครื่อง

1 (ชั่วโมง) → 2 → 4 → 8 → ไฟดับ (ยกเลิกการตั้งเวลา)

- เมื่อใช้งานโหมดตั้งเวลาปิดเครื่อง ไฟจะสลับไปเรื่อยๆ ตามเวลาคงเหลือที่ตั้งไว้ ซึ่งเมื่อครบตามเวลาที่ตั้งไว้แล้ว ตัวเครื่องก็จะหยุดทำงาน จากนั้นไฟปุ่มเปิด-ปิดเครื่องจะกะพริบประมาณ 5 นาทีและเครื่องก็จะดับลง

8 → 4 → 2 → 1 (ชั่วโมง) →ไฟดับ (หยุดการทำงาน)

การตั้งเวลาเปิด

- ทุกครั้งที่กดปุ่ม **Timer Preset** ในขณะที่เครื่องหยุดทำงาน ไฟจะสว่างขึ้นตามลำดับต่อไปนี้และเริ่มตั้งเวลาเปิดเครื่อง

1 (ชั่วโมง) → 2 → 4 → 8 → ไฟดับ (ยกเลิกการตั้งเวลา)

- เมื่อเริ่มตั้งเวลาเปิดเครื่อง ไฟจะสลับไปเรื่อยๆ ตามเวลาคงเหลือที่ตั้งไว้ ซึ่งเมื่อครบตามเวลาที่ตั้งไว้แล้ว ตัวเครื่องจะเริ่มทำงานตามค่าที่ตั้งไว้ในการใช้งานครั้งล่าสุด

8 → 4 → 2 → 1 (ชั่วโมง) →ไฟดับ (ตัวเครื่องเริ่มทำงาน)

การดูแลรักษา

- **กรุณาปิดเครื่องและถอดสายไฟก่อนการดูแลรักษาทุกครั้ง**

- **ห้ามใช้น้ำยาทำความสะอาด ทินเนอร์ เบนซิน และน้ำยาฟอกขาวในการทำความสะอาด**

ตัวเครื่อง

- กรุณาเช็ดทำความสะอาดด้วยผ้านุ่ม
- หากคราบสกปรกหลุดออกยาก ให้เช็ดออกด้วยผ้าชุบน้ำยาทำความสะอาดที่มีฤทธิ์เป็นกลางแบบเจือจางแล้ว จากนั้นเช็ดคราบน้ำยาทำความสะอาดออกให้หมดด้วยผ้าชุบน้ำบิดแห้ง



ฝาช่องดูดอากาศ แผ่นกระจายน้ำช่องดูดอากาศ

1 **ดึงบริเวณที่จับฝาช่องดูดอากาศเพื่อถอดออก**



(ต่อ) →

确认用

การดูแลรักษา (ต่อ)

2 ทำความสะอาดฝาช่องดูดอากาศและช่องดูดอากาศ

- ดูดคราบฝุ่นออกด้วยเครื่องดูดฝุ่นที่ติดตั้งหัวดูดแบบแปรง



*ด้านหลังฝาช่องดูดอากาศจะมีแผ่นกรองชั้นแรกและแผ่นกระจายน้ำติดอยู่ โปรดระมัดระวังเพื่อไม่ให้เกิดการชำรุดเสียหาย

3 ประกอบฝาช่องดูดอากาศ

- เสียบส่วนล่างของฝาช่องดูดอากาศกับตัวเครื่อง จากนั้นดันเขี้ยวล็อกที่ติดอยู่กับฝาช่องดูดอากาศเสียบเข้ากับตัวล็อกฝาช่องดูดอากาศบนตัวเครื่อง



ถังใส่น้ำ

1 ถอดถังใส่น้ำออก

- กดปุ่มถอดถังใส่น้ำค้างไว้แล้วดึงที่จับถังใส่น้ำเพื่อถอดออก



2 ทำความสะอาดภายในตัวเครื่อง

- หลังจากถอดถังใส่น้ำออกมา อาจมีน้ำจากช่องดูดน้ำหลงเหลืออยู่ กรุณาเช็ดออกให้สะอาด



3 ทำความสะอาดช่องดูดน้ำ

- หากกดที่คันโยกช่องดูดน้ำภายในตัวเครื่อง ช่องดูดน้ำจะลดระดับลงมา ซึ่งอาจมีขยะติดอยู่บริเวณช่องดูดน้ำได้ ให้ล้างออกด้วยน้ำแล้วเช็ดออกให้สะอาดด้วยผ้าบิดแห้ง
- หลังจากเช็ดเสร็จ ให้ยกช่องดูดน้ำกลับเข้าที่เดิมให้เรียบร้อย



确认用

4 ถอดแผ่นกรองในถังใส่น้ำออกแล้วล้างแผ่นกรองและถังใส่น้ำให้สะอาด



*หลังจากล้างเสร็จ ให้เช็ดหยดน้ำที่ติดอยู่ด้านนอกออกให้หมด แล้วประกอบเข้าที่เดิม
*ในการติดตั้งแผ่นกรองในถังใส่น้ำ โปรดหันด้านบน-ล่างให้ถูกต้อง



5 ประกอบถังใส่น้ำกลับเข้าที่

*เมื่อต้องการใช้งานโหมด Cold Wind กรุณาเติมน้ำลงในถังใส่น้ำ

การจัดเก็บ

เมื่อต้องการจัดเก็บตัวเครื่องไว้เป็นเวลานาน โปรดทำความสะอาดแผ่นกระจายน้ำ

1 ถอดฝาช่องดูดอากาศ

2 กางตัวล็อกทั้งสองฝั่งของแผ่นกรองที่อยู่ด้านหลังฝาช่องดูดอากาศออก และถอดแผ่นกระจายน้ำออกมา



*โปรดระมัดระวังเนื่องจากแผ่นกระจายน้ำอาจชำรุดได้ง่าย แม้ชำรุดเพียงเล็กน้อยจะยังใช้งานได้ก็ตาม แต่หากต้องการเปลี่ยนแผ่นกรองใหม่ โปรดติดต่อศูนย์บริการของไอริส (ดูที่ปกหลัง)

3 ล้างแผ่นกระจายน้ำ

• แช่แผ่นกระจายน้ำลงในน้ำสะอาดและล้างให้เกลี้ยง



*แผ่นกระจายน้ำอาจชำรุดได้ง่าย กรุณาล้างอย่างเบามือ
• ตากให้แห้งดีหลังจากล้างเสร็จ

● **ห้ามใช้น้ำยาทำความสะอาดหรือสารเคมี**
เพราะในการใช้งานครั้งต่อไปอาจมีส่วนผสมของน้ำยาทำความสะอาดและสารเคมีฟุ้งกระจายออกมาได้

4 ทำความสะอาดตัวเครื่อง ฝาช่องดูดอากาศ และถังใส่น้ำ

• ทำความสะอาดชิ้นส่วนต่างๆ ตามหน้า 11 – 13

5 ประกอบแผ่นกระจายน้ำ

• เสียบส่วนล่างของแผ่นกระจายน้ำเข้ากับฝาช่องดูดอากาศ จากนั้นกางตัวล็อกทั้งสองฝั่งของแผ่นกรองออกแล้วค่อยๆ ดันแผ่นกระจายน้ำเข้าไป



6 ประกอบชิ้นส่วนต่างๆ กลับเข้าที่

7 นำไปใส่กล่องบรรจุภัณฑ์หรือถุงพลาสติก แล้วเก็บไว้ในบริเวณที่มีความชื้นต่ำ

确认用

การแก้ไขปัญหา

กรณีที่เกิดความผิดพลาดขึ้นในระหว่างการใช้งาน ก่อนส่งซ่อม กรุณาอ่านคู่มือเล่มนี้โดยละเอียด แล้วตรวจสอบหัวข้อต่อไปนี้

ปัญหา	สาเหตุ	วิธีแก้ไข
ตัวเครื่องไม่ทำงาน (ไฟไม่เข้า)	● เสียบปลั๊กไฟเข้ากับเต้ารับไม่แน่น	● เสียบปลั๊กไฟเข้ากับเต้ารับให้แน่น
ตัวเครื่องสั่น	● วางตัวเครื่องในตำแหน่งที่ไม่มั่นคง	● กรุณาติดตั้งบนพื้นที่แนวระนาบที่มีความมั่นคง
มีน้ำรั่วออกมา	● ถังใส่น้ำมีปริมาณน้ำมากเกินไป	● เติมน้ำใส่ถังให้ไม่เกิน ● (น้ำเต็ม)
	● ใช้งานในตำแหน่งที่ไม่มั่นคง	● กรุณาติดตั้งบนพื้นที่แนวระนาบที่มีความมั่นคง
	● เคลื่อนย้ายตัวเครื่องขณะที่มีน้ำเหลืออยู่ในถัง	● เทน้ำในถังทิ้งก่อนเคลื่อนย้ายตัวเครื่อง
แรงลมน้อย	● มีฝุ่นติดอยู่ที่ช่องดูดอากาศและช่องปล่อยลม	● ทำความสะอาดตัวเครื่องและดูดฝุ่นออกให้หมด
ลมเย็นไม่ออกมา	● ไม่ได้ใช้งานโหมด Cold Wind	● กดปุ่ม **Cold Wind** ให้ไฟปุ่ม **Cold Wind** สว่างขึ้น
	● ใช้งานในจุดที่มีอุณหภูมิสูง	● หากใช้งานในจุดที่มีอุณหภูมิสูง จะทำให้น้ำระเหยได้ยากขึ้น และทำให้ลมเย็นได้ยากขึ้นอีกด้วย กรุณาใช้งานในบริเวณที่อากาศถ่ายเทได้ดี หรือใช้งานร่วมกับเครื่องปรับอากาศ
ลมเย็นไม่ออกมา (ไฟ Low Water กะพริบ)	● น้ำในถังใส่น้ำใกล้หมด	● หลังจากเติมน้ำและประกอบถังเรียบร้อยแล้ว กรุณากดปุ่ม **Cold Wind** ซ้ำ 2 ครั้ง
	● หลังจากประกอบถังใส่น้ำลงไป หากไม่กดปุ่ม **Cold Wind** ซ้ำ 2 ครั้งก็จะไม่เข้าสู่โหมด Cold Wind	● หลังจากเติมน้ำและประกอบถังเรียบร้อยแล้ว กรุณากดปุ่ม **Cold Wind** ซ้ำ 2 ครั้ง
เกิดข้อผิดพลาด (ไฟปุ่ม Timer Preset กะพริบ 2 ครั้งทุก 3 วินาที)	● วงจรภายในอาจชำรุดเสียหาย	● กรุณาติดต่อศูนย์บริการของไอริส

หากไม่สามารถแก้ไขปัญหาได้

กรุณาติดต่อร้านที่จำหน่ายผลิตภัณฑ์หรือศูนย์บริการของ Iris

● **ห้ามถอดแยก ซ่อมแซม หรือดัดแปลงผลิตภัณฑ์ด้วยตนเอง**

确认用

ข้อมูลทางเทคนิค

พิกัดแรงดันไฟฟ้า	220-240V~
พิกัดความถี่	50Hz
พิกัดกำลังไฟฟ้า	50W
ความจุถังใส่น้ำ (ปริมาณน้ำที่ใช้) (ประมาณ)	5.5L (4.2L)
ขนาดผลิตภัณฑ์ (ไม่รวมสายไฟ)	W298×D282×H752mm
น้ำหนักผลิตภัณฑ์ (ตัวเครื่องแห้งสนิท) (ประมาณ)	7.9kg
ความยาวสายไฟ (ประมาณ)	2m

* ข้อมูลทางเทคนิคของผลิตภัณฑ์อาจมีการเปลี่ยนแปลงโดยไม่แจ้งให้ทราบล่วงหน้า

การรับประกันและบริการหลังการขาย

โปรดอ่านเนื้อหาต่อไปนี้อย่างละเอียด

■ **ใบเสร็จรับเงิน**

กรุณาขอใบเสร็จรับเงินที่ร้านค้าปลีกเมื่อคุณซื้อผลิตภัณฑ์ คุณจะต้องชำระค่าธรรมเนียมการซ่อมแซมหากคุณไม่สามารถแสดงใบเสร็จรับเงิน ดังนั้นคุณต้องเก็บใบเสร็จรับเงินไว้ให้ดี

■ **ภายในระยะเวลารับประกัน**

ระยะเวลารับประกัน: จำกัดเวลาจะระบุไว้ในใบรับประกัน (ด้านหลัง)
บริษัทจะให้การซ่อมแซมโดยไม่คิดค่าใช้จ่ายตาม "ข้อกำหนดการรับประกัน" ภายใต้เงื่อนไขการทำงานที่ผิดปกติภายในระยะเวลารับประกัน

■ **หลังระยะเวลาการรับประกัน**

โปรดตรวจสอบกับร้านค้าปลีกและคุณต้องจ่ายค่าบริการที่เกี่ยวข้อง โดยหลังการซ่อมแซม คุณสามารถคงการใช้งานของผลิตภัณฑ์ได้ ซึ่งจะถูกเรียกเก็บเงินค่าซ่อมแซมบางชนิดตามความประสงค์ของลูกค้า

■ **ระยะเวลาที่เหลือของชิ้นส่วนอะไหล่**

ระยะเวลาที่เหลือของชิ้นส่วนอะไหล่หลักของบริษัท คือ 5 ปีหลังจากผลิตภัณฑ์หยุดการผลิต ชิ้นส่วนอะไหล่สำรองต้องได้รับการตรวจสอบเพื่อคงการใช้งานของผลิตภัณฑ์

■ **เกี่ยวกับบริการหลังการขาย**

โปรดตรวจสอบกับร้านค้าปลีกสำหรับบริการหลังการขายอื่นๆ

确认用

พัดลมไอเย็น KSWK-0603D **ใบรับประกัน**

ใบเสร็จรับเงินเป็นส่วนหนึ่งของใบรับรองเพื่อให้คุณรับบริการโดยไม่เสียค่าใช้จ่ายภายในระยะเวลาถัดไปนับจากวันที่ซื้อตามข้อกำหนดการรับประกันต่อไปนี้

วันที่ซื้อ* ระยะเวลารับประกัน	ระยะเวลารับประกัน **1 ปีนับจากวันที่ซื้อ** ยกเว้นอุปกรณ์เสริมและวัสดุสิ้นเปลือง

ลูกค้า	ชื่อ: รหัสไปรษณีย์: ที่อยู่: หมายเลขโทรศัพท์ ( ) -	*ร้านค้าปลีก	ชื่อร้าน: ที่อยู่: หมายเลขโทรศัพท์ ( ) -

สำหรับร้านค้าปลีก: โปรดกรอกข้อมูลในช่องที่มีสัญลักษณ์ * แล้วส่งไปยังลูกค้าของคุณ

ข้อกำหนดการรับประกัน

1 บริษัทจะจัดให้มีการซ่อมแซมหรือเปลี่ยนชิ้นส่วนโดยไม่คิดค่าใช้จ่ายในกรณีที่มีการทำงานผิดปกติ หรือความเสียหายที่เกิดขึ้นภายใต้สภาพการใช้งานปกติ โดยลูกค้าต้องให้ความสนใจคู่มือการใช้งานและฉลากบนผลิตภัณฑ์

2 การซ่อมแซมภายใต้การรับประกันสามารถทำได้โดยศูนย์บริการที่ได้รับอนุญาตเท่านั้น โดยต้องกรอกใบร้องเรียนการรับประกัน พร้อมแนบใบเสร็จชำระเงินตัวจริง (พร้อมวันที่ซื้อ)

3 เนื้อหาการรับประกันจะจำกัดอยู่ที่การซ่อมผลิตภัณฑ์โดยไม่คิดค่าใช้จ่ายเท่านั้น ไม่มีการรับประกันอื่นใดให้อีกแม้อยู่ภายในระยะเวลารับประกัน การรับประกันครอบคลุมเฉพาะข้อบกพร่องในวัสดุหรือกระบวนการผลิต

4 การรับประกันจะไม่ครอบคลุมกรณีต่อไปนี้:

① การชำรุดสึกหรอตามปกติ
② การใช้งานไม่ถูกต้อง เช่น การโหลดเกินพิกัดของเครื่อง ใช้อุปกรณ์เสริมที่ไม่ผ่านการอนุมัติ
③ ขัดข้องและเสียหายเกิดจากผลิตภัณฑ์ชนกระแทกหลังการซื้อ การใช้กำลังหรือความเสียหายที่เกิดจากการกระทำภายนอก
④ ขัดข้องและเสียหายที่เกิดจากไฟไหม้ แผ่นดินไหวหรือภัยธรรมชาติอื่นๆ
⑤ ความเสียหายที่เกิดจากการไม่ปฏิบัติตามคู่มือผู้ใช้ เช่น การเชื่อมต่อกับแหล่งจ่ายไฟไม่เพียงพอ หรือไม่ปฏิบัติตามคำแนะนำในการติดตั้ง
⑥ ขัดข้องและเสียหายระหว่างการจัดการและขั้นตอนการขนส่งหลังการซื้อ
⑦ ส่วนประกอบเครื่องใช้ไฟฟ้าบางส่วนหรือทั้งหมดถูกถอดออก
⑧ ไม่สามารถแสดงใบเสร็จรับเงิน
⑨ ใบรับประกันไม่ได้ระบุวันที่ซื้อ ชื่อลูกค้า ชื่อร้านค้าปลีก หรือข้อมูลข้างต้นใดๆ ถูกแก้ไข

5 ใบรับประกันมีผลบังคับใช้ในประเทศไทยเท่านั้น

6 ใบรับประกันจะต้องเป็นต้นฉบับและจะต้องเก็บไว้อย่างเหมาะสม

บันทึกข้อตกลงการซ่อมแซม

*ใบเสร็จรับเงินเป็นใบรับรองสำหรับการซ่อมและการเปลี่ยนโดยได้ระบุเงื่อนไขไว้ในคู่มือการใช้งานอย่างชัดเจน อย่างไรก็ตาม ใบรับประกันเป็นสิ่งรับรองว่าลูกค้าจะได้รับสิทธิทางกฎหมายจากบริษัท (ผู้รับผิดชอบการรับประกัน) และตัวแทนจำหน่ายของบริษัทโปรดตรวจสอบกับร้านค้าปลีกสำหรับปัญหาเกี่ยวกับการซ่อมหลังระยะเวลารับประกัน

*โปรดอ่านและทำความเข้าใจ “การรับประกันและบริการหลังการขาย” สำหรับการรับบริการหลังระยะเวลารับประกันและระยะเวลาการเก็บรักษาชิ้นส่วนอะไหล่

แบรนด์พรินซิเพิล: IRIS Ohyama Inc.,
ที่อยู่ : 2-12-1,Itsutsubashi,Aoba-ku,Sendai-shi,Miyagi-ken,Japan
ผู้จัดจำหน่าย :

IRIS OHYAMA(THAILAND) CO.,LTD.

ที่อยู่ : No. 399 Interchange 21, Room No. 2208, 22 Floor, Sukhumvit Road, Klongtoey Nua Sub-district, Wattana District, Bangkok 10110

170921-DZC-HYJ-04

确认用

品名：CTF-01M取説
サイズ：210×290　20ページ
材質：上質紙 菊判48.5kg（81.4g/㎡）
刷色：1C（Black）
Black

CTF-01M

WOOZOO®
by IRIS OHYAMA

Indoor/household use only

Air Cooler

KSWK-0603D

Instruction Manual



Contents

Preparations

Safety precautions..... 2
Usage precautions 4
Mechanism of the air cooler 4
Parts..... 5
Remote control 7

Operation instructions

Preparation..... 8
How to use 9
Cleaning and maintenance..... 11

Others

Troubleshooting 14
Specifications..... 15
Warranty and after-sales services 15
Warranty card.....Back cover

确认用

Safety precautions

Make sure to read the following “Safety precautions” first in order to use the product correctly.
The safety precautions describe the matters users required to observe in order to prevent personal injury or property damage.

Examples of symbols

This symbol means “Warning”	This symbol means “Prohibited”	This symbol means necessary “Recommend”

Warning

The symbol means risks which may lead to death or serious injury during faulty operation.

Handle the power plug and power cord correctly

Be sure to

- **Remove dust from the power plug with a dry cloth periodically**
  Collection of dust may cause poor insulation due to humidity, resulting in a fire or an electric shock.
- **Be sure to insert the power plug into the socket securely**
  Non-compliance may cause a short circuit, resulting in a fire or an electric shock.

Unplug the product

- **Be sure to remove the power plug from the socket when cleaning, inspecting or moving the product.**
  Non-compliance may cause an electric shock or physical injury.

Avoid contact with wet hands

- **Do not insert or remove the power plug from the socket with a wet hand**
  Non-compliance may cause an electric shock, a burn, or an injury.

Prohibited

- **Do not use the power cord and power plug if they are damaged or inserted loosely into the socket**
  Non-compliance may cause a short circuit, resulting in a fire or an electric shock. If the power cord is damaged, contact the Repair Call Center.

Prohibited

- **Do not turn on the power while the power cord is wrapped**
  Non-compliance may cause overheating, resulting in a burn or fire. Be sure to extend the cord when using it.
- **Do not damage the power cord**
- **Do not pull the power cord forcibly when transporting or storing the product**
  Do not damage or modify the cord, bend; stretch or twist the cord forcibly; place a heavy object on the cord; or put the cord between objects.
  Non-compliance may cause damage to the power cord, resulting in a fire or an electric shock.
- **Do not use the product if it is connected to a socket or extension cord that exceeds the rated capacity.**
  Non-compliance may cause a fire



- **Do not use the product at a voltage of less than 220-240V~**
  Non-compliance may cause a fire or an electric shock.
- **Do not let infants touch the power plug**
  Non-compliance may cause an injury or an electric shock.

Unplug the product

- **Stop using the product and remove the power plug from the socket immediately if there is any abnormality or malfunction**
  Non-compliance may cause fumes, a fire, or an electric shock.
  [Examples of abnormality]
  - **There is an unusual noise or smell**
  - **The power plug and power cord have abnormal overheating**
  - **The product turns on or off when the power cord is moved**
  - **The product turns off occasionally while it is in operation**
  - **The user feels an electric current running in the finger when touching the product**

  ➡ Stop using the product and contact the shop where you purchased the product or the Iris Call Center.

Prohibited

- **Do not use the product outdoors**
  Non-compliance may cause a malfunction, resulting in a short circuit or a fire.

Prohibited

- **Do not use the product near flammable substances (such as kerosene, gasoline, thinner, etc.) or combustible substances (cigarettes, incense sticks, etc.)**
- **Do not spray liquids (insecticides, hair care products, or lubricating oil) onto the product**
  Non-compliance may cause a fire.

Do not disassemble

- **Do not disassemble, repair, or modify the product**
  Do not disassemble the product except when removing the base to store the product. Non-compliance may cause a fire, an electric shock, or personal injury. It is dangerous for anyone except suitably qualified service staff to repair the product.
  For repair, contact the shop where you purchased the product or the Repair Call Center.

确认用

Prohibited

- **Do not use the product with the airflow from it facing heating equipment such as a heater**
  Non-compliance may cause incomplete combustion or flying sparks, resulting in carbon monoxide poisoning or a fire.



Avoid getting he product wet

- **Do not use the product in a humid place, such as a wet area or a bathroom**
- **Do not wet the product or immerse it in water**
  Non-compliance may cause a fire or an electric shock.

Caution

The symbol means risks which may lead to a personal injury or property damage if the product is used incorrectly

Prohibited

- **Do not expose yourself directly to the airflow from the product for a long time**
  Especially, be careful of not directly exposing a child or elderly person to the airflow from the product. Non-compliance may cause physical disorder or harm to their health.
- **Do not directly expose animals or plants to the airflow from the product**
  Non-compliance may harm animals or plants.

Water in the water tank

Be sure to

- **Replace the water every day**
  Wash the water tank every day in order to keep it clean always. If old water is used continuously, it may cause a smell or physical harm.
- **If the water tank has not been used for more than one week, be sure to drain the water tank and air-dry the evaporative cooling filter**
  If the filter is left wet, it may cause a smell or pollute the air around the product.
- **Drain the water tank if it is likely to freeze**
  If the water tank freezes, it may cause a malfunction or water leakage, resulting in soiling around the product.

Prohibited

- **Use clean water only**
  Do not use hot water exceeding 40°C, chemical substances, aromatics (aromatic oil etc.), mineral water, alkaline ionized water, contaminated water, etc.
  Non-compliance may cause an odor or pollute air around the product. Also, non-compliance may cause distortion, cracking, discolor, etc., resulting in water leakage.

Unplug the product

- **Be sure to remove the power plug without holding the power cord when removing it from the socket**
  Non-compliance may cause damage to the power cord, resulting in a fire or an electric shock.
- **Remove the power plug from the socket when it is not being used for a long time**
  Non-compliance may cause a fire or an electric shock.

Be sure to

- **Use the product on a horizontal and stable floor**
  If the product is used on a thick carpet, futon or table, it may cause the product to fall down, resulting in water leakage or physical injury.

Prohibited

- **Do not let persons who are not used to handling the product, including children, use the product alone, nor let children touch it**
- **Do not climb or lean on the product**
  Non-compliance may cause a physical injury or an electric shock.
- **Do not move the product with water contained in the water tank**
  If the product is moved with water contained in the water tank, it may cause water leakage when it is tilted.
  Drain the water tank before moving the product.

Prohibited

- **Do not use the product around any object that blocks the airflow**
- **Do not operate the product while it is covered with cloth, paper, a plastic bag, etc**
- **Keep the rear side of the product more than 5cm away from a wall**
- **Keep yourself more than 30cm away from the front side of the product**
  If the airflow is blocked, it may cause overheating, resulting in a fire.



Prohibited

- **Do not use the product for any purpose other than household use, such as industrial use**
  This product is designed for household use only. If this product is used for any purpose other than household use, such as industrial use, it may cause a fire, etc.

确认用

Safety precautions (continued)

Prohibited

- **Do not run the product while using a fumigant that issues smoke or mist**
  Non-compliance leads to the accumulation of chemical substances in the evaporative cooling filter, which may cause physical harm when they are released in the subsequent operation.
  After using the fumigant, ventilate the surrounding area well before running the product.

Prohibited

- **Do not put your finger or a metal object into the air outlet, air inlet, or other gaps in the unit**
  Non-compliance may cause an electric shock or injury.

Usage precautions

- **Avoid using the product in a place which is exposed to high humidity or oil and smoke, such as a kitchen**
  If the product is used in such a place for a long time, it may cause the inside of the product to gather dust, which cannot be removed completely by a vacuum cleaner.
- **Install the product in a place that is not exposed to direct sunlight, or wind from an air conditioner or a heater.**
  Non-compliance may cause deformation or discoloration of the product, resulting in a malfunction.
- **Keep the product away from a radio or TV**
  Non-compliance may cause an abnormal noise.

Disposal

- **This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**
  Children should be supervised to ensure that they do not play with the appliance.

Mechanism of air cooler



* As the air cooler evaporates water to cool the air, the humidity level will rise when it is used in a closed room. If the product is used in a highly humid place, it may have difficulty to evaporate the water, resulting in a lower cooling effect. Use the product in a well-ventilated place, or together with an air conditioner.

* Be sure to put water in the tank in order to run the product with a cold wind. The product does not blow cold wind if the water tank does not contain water.

确认用

Parts

Front



Back (inside)



确认用

Parts (continued)

Control panel

Low Water alarm lamp
If the water tank becomes nearly empty while the product is running with cold wind, the Low Water alarm lamp will flicker and the product will run without a cold wind. (→P10)



Cold Wind lamp and button
This button switches the cold wind on or off cold. (→P9)

Mode lamp and button
This button switches the operating mode. (→P10)

Speed lamp and button
This button switches the speed of the airflow. (→P9)

Swing lamp and button
This button switches the left and right airflow swing on and off. (→P10)

Timer Preset lamp and button
By pressing this button while the power is on, the OFF time can be preset. By pressing this button while the power is off, the ON time can be preset(→P11)

Power lamp and button
The power of the product turns on by pressing this button. By pressing this button again, the power turns off and the product stops running. (→P9)

Accessories



Cooling pack x 2



AAA battery x 2
(for operation verification)

Remote control unit

确认用

Remote control

* Point the infrared light emitting unit of the remote control at the light receiving unit on the front side of the main body.



Infrared light emitting unit

Swing button
This button has the same function as the Swing button on the main body. (→P10)

Speed +/- button
The airflow speed increases by pressing the + button and decreases by pressing the - button. (→P9)

Mode button
This button has the same function as the **Mode button** on the main body. (→P10)

Power button
This button has the same function as the **Power button** on the main body. (→P9)

Timer Preset button
This button has the same function as the **Timer Preset button** on the main body. (→P11)

Cold Wind button
This button has the same function as the **Cold Wind button** on the main body. (→P9)

How to install the batteries

- First, install two AAA batteries.
- * The batteries supplied with the product as accessories are for operation verification. Replace them with new batteries as soon as possible.
- If the operating range becomes narrower or the remote control does not operate by pressing the button, replace the batteries (AAA batteries x 2) as soon as possible.

Open the battery lid and replace the batteries

① Slide the battery lid downwards while holding it down in order to open it.
② To replace the batteries, remove the used batteries and install new batteries with their ⊕ and ⊖ ends in the correct direction respectively.
③ Close the battery lid securely.



● **Improper use of batteries may cause a rupture or leak from batteries, a burn, or soiling around the product. Read the "Precautions about batteries" section carefully.**

Precautions about batteries

Be sure to

● **Note the polarity indication (position of the ⊕ and ⊖ ends) carefully when installing a battery in the remote control, and install the battery correctly as per the instructions.**
Non-compliance may cause a rupture or leak from the batteries, resulting in a fire, a physical injury, or soiling around the product.

● **Remove the batteries when the product is not used for a long time**
Non-compliance may cause a leak from the batteries, resulting in a fire or soiling around the product.
If a battery has leaked, wipe away the battery leakage off the battery case completely before installing a new battery. If leakage material gets stuck to a part of your body, flush it with water.

Do not disassemble

● **Do not disassemble the product**
Non-compliance may cause damage to the skin or clothes.

Prohibited

● **Do not carry or store batteries together with metal items**
Non-compliance may cause a short circuit, resulting in a rupture or leakage from the batteries.

● **Do not use any battery except the designated batteries**
Non-compliance may cause a rupture or leakage from the batteries, resulting in a fire, physical injury, or soiling around the product.

● **Do not recharge the batteries**
Non-compliance may cause a rupture or leakage from the batteries, resulting in a fire, physical injury, or a burn.

确认用

Preparation

Add water to the water tank

- Put water in the water tank to run the product with a cold wind.
- * The product can run without water in the case of running it without the cold wind.

1 Remove the water tank

- Hold the water tank handle and pull out the water tank while holding down the water-tank eject button.
- Water remaining in the evaporative cooling filter drips down immediately after the product stops running. Do not pull out the water tank while the **Power** lamp is flickering (wait for five minutes).



2 Add water to the water tank

- Add water to the water storage tank (right)
- Be sure to add water to the level that is higher than ○ (Water supply) and lower than ● (Full).



3 Install the water tank

- Insert the tank Securely
- If the water inlet is lowered, install the water tank after bringing it up. (→ P12)



- **Always use normal tap water. Do not use hot water exceeding 40°C, contaminated water, mineral water, alkaline ionized water, well water, etc.**
- **Do not add chemical substances, aromatics, essential oil, etc. into the water.**
  Non-compliance may cause mold and germs to grow easily, or soil the filter, resulting in a smell and physical harm.

How to use the cooling pack

- Put the cooling pack under water in the water storage tank of the water tank after freezing it in the freezer. By doing so, the temperature of cold wind can be lowered.



- To freeze the cooling pack again, put it in the freezer after completely wiping water off its surface.

- **Always keep the cooing pack clean**
  Especially, wash the cooing pack before placing it next to food in the freezer.

Put the power plug into the socket



确认用

How to use

To start running the product

Press the Power button while the product is not running

- If the power plug is not removed, the product will start under the previous settings.
- The product can be started by pressing the **Power** button of the remote control unit.

* The ON timer is reset by starting the product.

To stop the product

Press the Power button while the product is running

- The product can be stopped by pressing the **Power** button of the remote control unit.
- The product stops running, and then its **power** turns off after the Power lamp flickers for five minutes.
- Water remaining in the evaporative cooing filter drips down immediately after the product stops running. Do not drain the water tank while the **Power** lamp is flickering.

* The OFF timer is reset by stopping the product.



Auto-stop function

- If the product is left unattended for 15 hours, it will stop running and its power turns off.

Cold Wind

- By pressing the **Cold Wind** button while running the product, it starts running with a cold wind.
- By pressing the Cold Wind button again, the product stops running with a cold wind and shifts to blowing air only.



* To run the product with cold wind, add water to the level that is higher than ○ (Water supply) and lower than ● (Full). (→P8)

Airflow speed switching

- The airflow speed changes by pressing the **Speed** button while running the product, as indicated below.



→ 1 → 2 → 3 → 4

- On the remote control, the speed increases by pressing the **Speed** + button, and decrease by pressing the speed – button.



1 ↔ 2 ↔ 3 ↔ 4

确认用

How to use (continued)

Mode switch

- The operating mode changes by pressing the **Mode** button while running the product, as follows.



→ **General** → **Natural** → **Sleep** ⌐

General	Runs the product at the airflow speed preset by the **Speed** button.
Natural	Reproduce a semi-natural flow of air (natural wind) by changing the airflow speed.
Sleep	Reduce the airflow speed gradually while running the product with natural airflow mode.

Swing

- By pressing the **L&R Swing** button while the product is running, the product swings horizontally.
- The swing mode stops by pressing the **L&R Swing** button again.



Adjustment of the vertical airflow

- The direction of the vertically-movable louvers can be adjusted manually.



If the Low Water lamp flickers

- If the water tank becomes nearly empty while the product is running in cold wind mode, the product starts to run without a cold wind.
- The **cold wind** lamp turns off and the Low Water lamp flickers.



- Add water to the water tank and reinstall it (→P8).
  By pressing the **Cold Wind** button twice, the Low Water lamp turns off and the product starts running with the cold wind again.



* Apart from when the water level becomes low, the Low Water lamp also flickers when the water tank is installed or removed. To run the product with the cold wind, press the **Cold Wind** button twice after installing the water tank correctly.

确认用

■ Timer Preset

OFF timer

- The lamp turns on by pressing the **Timer Preset** button while running the product, as indicated below, and the OFF timer starts.

→ **1** (hour) → **2** → **4** → **8** → Off (the timer resets)

- If the product is run with the OFF timer enabled, the lamp switches according to the time remaining. The product stops running when the preset time has elapsed, and after the **Power** lamp flickers for five minutes, the power turns off.

8 → **4** → **2** → **1** (hour) → Off (Stop)

ON timer

- The lamp turns on by pressing the **Timer Preset** button while the product is stopped, as indicated below, and the ON timer starts.

→ **1** (hour) → **2** → **4** → **8** → Off (the timer resets)

- If the ON timer is activated, the lamp switches according to the time remaining. The power turns on when the preset time has elapsed, and the product starts running under the previous settings.

8 → **4** → **2** → **1** (hour) → Off (Stop)

Cleaning and maintenance

- **Conduct the maintenance of the product after stopping running the product and remove the power cord from the power outlet socket.**

- **Do not use a cleaner, thinner, benzene, bleacher, etc.**

■ Main body

- Wipe the main body of the product with a dry cloth.
- If the main body of the product is heavily stained, wipe it with a cloth soaked in diluted neutral detergent. Then, wipe any remaining detergent off with a well-wrung cloth, etc.



■ Air inlet cover, evaporative cooling filter, air inlet

1 Pull the air inlet cover handle to remove the cover



(Continued)→

确认用

Cleaning and maintenance (continued)

2 Clean the air inlet cover and air inlet

- Remove dust by a vacuum cleaner's brush nozzle.



* The back of the air inlet cover has a prefilter as well as an evaporative cooling filter. Handle them with care so that they are not damaged.

3 Attach the air inlet cover

- Put the bottom of the air inlet cover in the main body, and put the cover retaining hooks of the air inlet cover onto the air inlet cover holder of the main body.



■Water tank

1 Remove the water tank

- Hold the water tank handle and remove the water tank while holding down the water-tank eject button.



2 Clean inside the main body

- After removing the water tank, water may drip down through the water inlet. In this case, wipe any water from the inside of the main body.



3 Clean the water inlet

- The water inlet goes down by pressing the water inlet lever in the main body. As the water inlet may gather dust etc., wipe it with a cloth (cloth soaked in water and then wrung out well).
- After wiping the water inlet, bring it up so that it returns to its original position.



确认用

4 Remove the filter of the water tank and wash the filter and water tank with water



* Wipe water drops from the outside of the water tank after washing the water tank, and reinstall the water tank.
* Install the filter of the water tank in the correct vertical direction.



5 Reinstall the water tank

* Add water to the water tank to run the product with the cold wind.

■ Storing the product

Conduct maintenance of the evaporative cooling filter before storing it for a long time.

1 Remove the air inlet cover

2 Pull the filter holders on the back of the air inlet cover sideways to remove the evaporative cooling filter



* Handle the evaporative cooling filter with care, as it is fragile. The filter is still usable even if there is slight damage on a corner. To purchase a new filter, contact the Iris Call Center (see the back cover of this manual).

3 Wash the evaporative cooling filter with water

- Soak the filter in clean water to wash it.



* Do not splash water on the filter powerfully, as it is fragile.
- Dry the filter well after washing it.

● **Do not use a cleaner or a chemical substance**
A cleaner or a chemical substance may scatter when the product runs after maintenance.

4 Conduct maintenance of the main body, air inlet cover, water tank, etc.

- Conduct maintenance of the main body, air inlet cover, water tank, etc. as per the instructions in P11-13.

5 Install the evaporative cooling filter

- Put the bottom of the evaporative cooling filter in the air inlet cover, and gently push the evaporative cooling filter inwards while pulling the filter holders sideways.



6 Reinstall the air inlet cover on the product

7 Put the product in a storage box or a plastic bag and store it at a place that has low humidity

确认用

Troubleshooting

If any abnormality occurs while operating the product, please read this instruction manual carefully and check the following points before requesting the repair service.

State	Causes	Measures
The product does not work (the power cannot be turned on)	● The power plug is not inserted into the power outlet socket securely	● Insert the power plug into the socket securely.
The product vibrates	● The product is wobbly due to poor installation	● Install the product at a horizontal and stable location.
Water leaks	● The level of water in the water tank is too high	● Add water to the water tank to the level not exceeding ● (Full).
	● The product is used in an unstable location.	● Install the product at a horizontal and stable place.
	● The product is moved with water contained in the water tank	● Drain the water tank before moving the product.
The airflow speed is low	● The air inlet and outlet are clogged with dust	● Conduct maintenance of the product to remove any dust accumulation.
Cold wind is not blown	● Cold wind mode is disabled	● Press the **Cold Wind** button to turn on the **Cold Wind** lamp.
	● The product is used in a highly-humid place	● If the product is used in a highly-humid place, it will be difficult to evaporate the water, reducing the effect of the cold wind. Use the product in a well-ventilated location or together with a suitable air conditioner, etc.
Cold wind is not blown (the Low Water alarm lamp flickers)	● The water storage tank is nearly empty	● Press the **Cold Wind** button twice after adding water to the water tank and installing it correctly.
	● The product cannot run with the cold wind if you do not press the **Cold Wind** button twice after installing the water tank	● Press the **Cold Wind** button twice after adding water to the water tank and installing it correctly.
Error indication (the Timer Preset flickers twice every three seconds)	● The internal circuit may have a malfunction	● Contact the Repair Call Center.

If you cannot resolve the problem after implementing the above actions;

Contact the shop where you purchased the product or the Iris Call Center.

● **Do not try to disassemble, repair, or modify the product yourself.**

确认用

Specifications

Rated voltage	220-240V~
Rated frequency	50Hz
Rated consumption power	50W
Capacity of the water tank (effective water volume) (about)	5.5L (4.2L)
Size (not including the power cord)	W298×D282×H752mm
Weight (when the product is dry) (about)	7.9kg
Length of the power cord (about)	2m

* The specification of the product is subject to change without prior notice.

Warranty and after-sales services

Please make sure to carefully read the following contents.

Purchase Receipt

Be sure to request a Purchase Receipt at the retail shop when purchase the product.
The repair fee needs to be paid if you are unable to present a Purchase Receipt. Therefore, you must keep the Purchase Receipt securely.

Within the warranty period

Warranty period: Time limit specified by the warranty card (Back cover).
The company will provide free repair as per the “Warranty Provisions” under abnormal operating conditions within the warranty period.

Over the warranty period

Please check with retail shop and you will have to pay for related repair expenses. It will be possible to maintain the functions of the product after repair. A certain repair cost will be charged according to customer’s requirements.

About the remaining period of spares parts

The remaining period of the company's major spare parts is 5 years after stopped production of this product. The spare parts in operation correspond to the spare needed to maintain the functions of parts needed to maintain the functions of the product.

About after-sales service

Please check with retail shop for other after-sales issues.

确认用

Air Cooler KSWK-0603D

Warranty card

The purchase receipt constitutes the certificate so you can enjoy free repairs in accordance with the following repair provisions within the next period from the day of purchase.

Purchase date* Warranty period	Warranty period **1 years from the day of purchase** *Except for consumables

Customer	Name: Postal code: Address: Telephone number ( ) -	*Retail shop	Shop name: Address: Telephone number ( ) -

Notice to retail shops: Please fill in the fields marked with a * symbol and then deliver it to your customer.

Warranty provisions

1 The company will provide free repairs or replacements in conditions of malfunction or damage present under normal operating conditions as per the aspects that must be given attention according to the labels affixed on the operation manual and the product.
2 Warranty repairs can only be performed by an authorised service centre. When filling a warranty claim, the original bill of purchase (with the date of purchase) must be submitted.
3 The warranty contents are only limited to the free repair of the product. No other warranty service is provided even within the warranty period. The warranty only covers defects in materials or workmanship.
4 The warranty will not apply in cases of:
① Normal wear and tear
② Incorrect use, e.g. overloading of the appliance, use of non-approved accessories
③ Failures and damages caused by product crashes after purchase. The use of force or damage caused by external influences
④ Failures and damages caused by fires, earthquakes or other natural disasters
⑤ Damage caused by non-compliance with the user manual, e.g. Connection to an inadequate power supply or non-compliance with the installation instructions
⑥ Failures and damages during the handling and transportation process after purchase
⑦ Partially or completely dismantled appliances
⑧ Not being able to show the purchase receipt
⑨ The warranty card has not been filled with the date of purchase, the customer's name, the name of the retail shop or any of the above data has been modified
5 The warranty card is only valid in THAILAND.
6 The warranty card must be the original and must be kept appropriately.

Repair memorandum

* The purchase receipt constitutes the certificate corresponding to the repair and replacement conditions clearly stipulated in the user manual. However, the warranty card restricts any customer from enjoying any legal rights from the company (person responsible for the warranty) and any dealer.
Please check with retail shop for repair-related matters after the warranty period.
* Please check the "Warranty and after-sales service" for any repairs after the warranty period and the remaining period of spare parts.

Brand Principal : IRIS Ohyama Inc.,
Address : 2-12-1,Itsutsubashi,Aoba-ku,Sendai-shi,Miyagi-ken,Japan
Distributor :
IRIS OHYAMA(THAILAND) CO.,LTD.
Address : No. 399 Interchange 21, Room No. 2208, 22 Floor, Sukhumvit Road, Klongtoey Nua Sub-district, Wattana District, Bangkok 10110

250222-DZC-HYJ-04

确认用