

CODE : 865754 ⊕ TH取説 T A F - M K M 1 0  
サイズ : 210mm×148mm (A5) 12 ページ  
材質 : 上質紙 四六判 70kg (81.4kg)  
刷色 : 1C (Black)

EN

TAF-MKM10

K

WOZZOO®  
by IRIS OHYAMA

Indoor/Household Use Only


# Table Fan

## TAF-MKM10

---

# User manual

---



## Contents

### Preparations


Safety precautions .....	2
Using precautions .....	5
Parts .....	6

### Operation instructions

Operation instructions .....	7
Cleaning and maintenance .....	8

### Others

Troubleshooting .....	9
Specifications .....	10
Warranty and after-sales services .....	11
Warranty card .....	Back cover



## Safety precautions

In order to avoid causing injury to you and others bringing unnecessary property loss please read carefully observe the following "Safety Precautions" before use.

### Examples of symbols



This symbol means "reminding".



This symbol means "forbidden".



This symbol means necessary "instructions".



### Warning

The symbol means matters which may lead to death or serious injury during faulty operation.

#### Use power plug and power cord correctly



Be sure to

- **Remove dust from power plug regularly**  
When dust is allowed to build up, insulation is hampered due to moisture, which can cause fire or electric shock.
- **Insert the power plug securely all the way to the electric socket**  
Failure to do so may cause fire or electric shock due to short circuit.

---

- **The product can only be powered by 220V~**  
Failure to do so may cause fire.
- **Please do not use the product with the power cord tangled**  
Failure to do so may cause fire. Please do not use when the electrical cord is in a knot or bundle.
- **Stop using the product with a faulty power cord, plug or a loose power socket**  
Otherwise it may cause electric shock or injury.
- **Do not damage the power cord**  
Do not damage, processing, forcefully bend, pull, twist or squeeze the power cord, or place weight on it.  
Failure to do so may cause fire or electric shock due to damage to the power cord.
- **Do not stretch the power cord when moving or storing it**  
Failure to do so may cause fire or electric shock.




Be sure to

- **This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance**



Be sure to

- **If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard**





Avoid contact  
with wet hands

- **Do not insert or unplug the power plug with wet hands**  
Failure to do so may result in electric shock, burn or injury.



Unplug the  
product

- **Make sure to unplug the power plug from the power socket before performing repairs, checks or transfers**  
Failure to do so may result in electric shock or injury.



Do not  
disassemble

- **No disassembly, repair or transformation of this product is allowed**  
Failure to do so may result in fire, electric shock or injury.  
Please check with the retail shop by calling the consultation number for related matters.




Avoid getting  
the product wet

- **Please do not use this product near a water source, a bathroom or a wet and damp environment**
- **Do not soak the main body of the product in water or pour water on it**  
Failure to do so may cause fire or electric shock.



Be sure to

- **In case of abnormality or breakdowns, please stop using and immediately turn off the power supply and pull out the plug from the power socket**  
Failure to do so may result in fire or even electric shock.  
**[Cases for abnormalities]**
  - Abnormal heating of the power plug and cord
  - Power on intermittently when power cord is moved
  - Abnormal sounds or peculiar smells
  - Breakdowns during operation
  - Burning pain caused by electric shocks when touching the product with the hands➔ Please stop using and check with the retail shop by calling the consultation number for related matters.




## Safety precautions continued



Prohibited

- Do not spray on the product (Such as insect killer, hair dressing or grease)
- Keep the product away from flammable substances (Kerosene, gasoline and paint thinner, etc.), objects with sparks (Cigarettes, incense, etc) or flammable dust

Failure to do so may cause fire.



Prohibited

- Do not direct this product to heating equipment such as home-heaters


Failure to do so may cause sparks, carbon monoxide poisoning, fire, etc. due to incomplete combustion of the heater.



Prohibited

- The product is utilized indoors only
- Do not use the product around any object that hinders ventilation
- Do not cover the product with combustible items such as clothing, paper or plastic bags before use
- Do not use the product in a place with too much dust or powder

Failure to do so may cause fire or electric shock due to short circuit.



### Caution

Faulty operation may lead to personnel injury or article damage.



Prohibited

- Please do not use the product other than for residential purposes

This product is designed as a residential product. Please do not use the product other than for residential purposes, otherwise it may cause accident.

- Do not use it for any purpose other than electric fan

Failure to do so may cause abnormality or fire.




Prohibited

- Please do not insert your fingers into the gap of the shield and keep away from the fan blade

Otherwise it may cause injury.

- Do not operate the product if front shield is not installed

Failure to do so may result in fire, electric shock or injury.






Prohibited

- **Do not strike the main body of the product**  
Failure to do so may cause malfunction, fire or electric shock.
- **Do not allow children or first time users to operate it alone, and do not use in close proximity of children**
- **Do not sit or lean on the product**  
Otherwise it may cause electric shock or other injuries.
- **Do not drag and move this product**  
Failure to do so may cause scratches on the tatami or floor.



Prohibited

- **Do not blow directly on any pet or plant**  
Failure to do so may affect the health of your pets and hinder the growth of your plants.



Be sure to

- **Please use this product on level and sturdy surfaces**  
Or it may lead to personnel injury or damage to the surrounding property.
- **Do not use the product near rolled-up curtains**  
Or it may lead to damage to surrounding property or injury.



Unplug the product


- **Make sure to hold the power plug when unplugging it**  
Otherwise it may cause fire or electric shock due to damaged power cord.
- **Unplug the power plug when the product is not in use**  
Otherwise it may cause fire or electric shock because insulation is hampered and electric leakage.

## Using precautions


- **Please do not place the product near the direct radiation of the sun, air conditioning or a heating stove.**  
Failure to do so may lead to deformation or discoloration of the product, which may result in malfunction.
- **Do not clean with chemicals such as discoloring agents, volatile oils, thinner etc.**  
Otherwise it may lead to discoloration or transformation.
- **Do not operate the product around a radio or TV.**  
Otherwise electromagnetic interference may affect the normal operation of the product.

# Parts

## ■ Front




## ■ Back




# Operation instructions

## ■ Operation Instructions


- ① Please set up on the flat, stable place, and insert the power plug into the socket.



- ※ Please confirm that the power ON/OFF is OFF before plugging into the power socket.



- ② Rotate the power ON/OFF to select the proper air volume.





- Rotate the power ON/OFF to off to stop.

## ■ Oscillating

### Horizontal direction

- The oscillating (Left/Right) is on when rotating the power ON/OFF towards the oscillating.




About 65°

- Please use “oscillating → stop” by the power ON/OFF to change the oscillating angle. (The angle can not be changed by hand.)

### Vertical direction (Manual)

- It can be adjusted by 6 stages, ranging from 22.5° downwards to 90° degrees upwards.



# Cleaning and maintenance




- Make sure to turn off the power supply and disconnect the power cord.

- After use of the product, the motor will stay hot for a certain period of time. Make sure to perform maintenance after the motor has cooled down.

## ■ Main body

Wipe with a soft and dry cloth.

- If it is difficult to clean the dirt, remove it with a cloth with diluted neutral detergent, and repeatedly wipe it until the detergent is completely removed.




## ■ Storage method

Cover the main body of the product with a plastic bag and then store it in a dry and cool place outside the direct action of the sunlight, when you are going to stop using it for extended periods of time.

## ■ Disposal

Please dispose the product and packing materials in accordance with local regulations.



# Troubleshooting

Please confirm the following problems after reading the operation manual carefully before you entrust to repair it.

State	Cause	Measures
Out of operation	<ul style="list-style-type: none"> <li>The power plug is not inserted properly into the power socket</li> </ul>	<ul style="list-style-type: none"> <li>Please insert the power plug securely into the socket.</li> </ul>
Low air volume	<ul style="list-style-type: none"> <li>Dust accumulation</li> </ul>	<ul style="list-style-type: none"> <li>Please maintain the product and clean the dust periodically.</li> </ul>
High operating noise	<ul style="list-style-type: none"> <li>The product is not placed in a level surface and the main body rocks</li> </ul>	<ul style="list-style-type: none"> <li>Please use this product on a smooth table.</li> </ul>
	<ul style="list-style-type: none"> <li>The front shield is not firmly installed</li> </ul>	<ul style="list-style-type: none"> <li>Please insert the front shield firmly.</li> </ul>
The product is emitting a squeaky sound when oscillating	<ul style="list-style-type: none"> <li>When the product oscillates, the electric motor's unique sound becomes louder</li> </ul>	<ul style="list-style-type: none"> <li>It is normal.</li> </ul>


## If you still cannot solve the problem

Please check with the retail shop by calling the consultation number.



● Do not disassemble, repair or transform the product without approval.






## Specifications

Rated voltage	220V~
Rated frequency	50Hz
Rated power	13W
Power cord length (About)	1.4m
Product size (About) (Without power cord)	W170.3×D125.5×H209.2mm
Product weight (About)	0.9kg

※ The specifications may be changed with no additional notification.



## Warranty and after-sales services

Please make sure to carefully read the following contents.

### ■ Purchase receipt

Be sure to request a Purchase Receipt at the retail shop when you purchase the product. The repair fee needs to be paid if you are unable to present a Purchase Receipt. Therefore, you must keep the Purchase Receipt securely.

### ■ Within the warranty period

Warranty period: Time limit specified by the warranty card (back cover).  
The company will provide free repair as per the "Warranty Provisions" under abnormal operating conditions within the warranty period.

### ■ Over the warranty period

Please check with your retail shop and you will have to pay for related repair expenses. It will be possible to maintain the functions of the product after repair. A certain repair cost will be charged according to customer's requirements.

### ■ About the remaining period of spares parts

The remaining period of the company's major spare parts is 5 years after stopped production of this product. The spare parts in operation correspond to the spare needed to maintain the functions of parts needed to maintain the functions of the product.

### ■ About after-sales service

Please check with retail shop for other after-sales issues.